

# Open eVision Deep Learning Studio

Deep Learning training and evaluation application

10				
NO. THE THE PART	The second second			euresys
		Test address 414 1		
sporter physical system provide	A Departments - & Operationage			
And add to N	-	And a local diversity of the local diversity	INCOMENTATION AND INCOMENTATION OF	
induce manage (1992) IE R				
and a				
A LOSS AND AND AND ADD				

## At a Glance

- Ease the evaluation of Open eVision's Deep Learning tools
- Dataset creation and image annotation for classification, segmentation, and object localization
- Create and configure dataset splits to decide how your images are used
- Manage the data augmentation transformations
- Train your tools in succession thanks to the training queue
- Validation and analysis of the results of the trained tools
- Available on Windows and Linux
- Free of charge

# **Benefits**

## **Open eVision Deep Learning Studio**

Open eVision Deep Learning Studio is an application that assists the user during the creation of the dataset as well as the training and testing of the Deep Learning tools of Open eVision.

Open eVision Deep Learning Studio is free and does not require any license. It allows you to test the Deep Learning libraries using your own images. No programming is required.

Just click on DOWNLOAD OPEN EVISION DEEP LEARNING STUDIO and install Open eVision. Sample images, manuals and example programs are included.

## **Deep Learning projects**

A Deep Learning Studio project manages your dataset and the Deep Learning tools you created. A project is associated with one the Deep Learning tool (EasyClassify, EasySegment Unsupervised, EasySegment Supervised or EasyLocate) and supports all their features.

Within a project, you can create as many tools as you want. It allows you to easily experiment with the parameters of the tools, different split of the dataset, or data augmentation settings.

## Control how your images are used

Deep Learning Studio allows you to split your dataset into training, validation, and test sets. You can create multiple dataset splits to experiment and check the performance of tools trained with different set of images.

You can create dataset splits at random or manually select the set of each image.

## **Data augmentation**

The rich data augmentation capabilities of EasyClassify, EasySegment, and EasyLocate are available in Deep Learning Studio. Tune and visualize the geometric, color, and noise data augmentations. You can create different set of data augmentation settings to experiment how it influence your results.

## Configure and train your tools

The Tools tab allows you to configure and train your tools. Operating on CPU or GPU, the training can be stopped and restarted at any time. You can launch as many training as you want thanks to the processing queue. The training and inference operations will be queued and processed one after the other.

## Validation and result analysis

The validation process is customized for each library to allow you to get the most out of your data. A comprehensive set of metrics, tables, and/or graphs is available to analyze and explore the results of the training process.

Tables and confusion matrixes allow you to filter your results to understand the strengths and weaknesses of the trained models. Score histograms and ROI curves are useful to select a threshold and adapt the trained models to your needs.

## Annotate your dataset

Deep Learning Studio integrates annotation tools adapted to each library. For classification and unsupervised segmentation, you can quickly assign label to each image. For supervised segmentation, the segmentation editor allows you to draw the ground truth segmentation. For localisation, the object editor allows you to quickly draw the bounding box around each of your objects.

The image editor also allows you to select a region of interest and mask parts of your image.

## **Applications**

## Machine Vision for the Electronic Manufacturing Industry

- High speed image acquisition for AOI, 3D SPI, 3D lead/ball inspection machines.
- Very high resolution line-scan image acquisition for Flat Panel Display inspection and solar cell inspection

## Machine Vision for the General Manufacturing Industries

- High frame rate image acquisition for inspection machines
- Line-scan image acquisition for surface inspection machines
- Line-scan image acquisition for textile inspection

## Machine Vision for the Printing Industry

• High speed line-scan image acquisition for printing inspection machines

## Video Acquisition and Recording

• High-frame-rate video acquisition for motion analysis and recording

# **Specifications**

## Software

Host PC Operating System	• Microsoft Windows 11, 10, 8.1, 7 for x86-64 (64-bit) processor architecture	
	<ul> <li>Microsoft Windows 10, 8.1, 7 for x86 (32-bit) processor architecture</li> </ul>	
	<ul> <li>Linux for x86-64 (64-bit) processor architectures</li> </ul>	
	Minimum requirements:	
	- 8 GB RAM	
	<ul> <li>400 MB free hard disk space</li> </ul>	

Product code - Description



#### EMEA

#### **Euresys SA**

Liège Science Park - Rue du Bois Saint-Jean, 20 4102 Seraing - Belgium

Phone: +32 4 367 72 88 Email: sales.europe@euresys.com

#### EMEA

#### Sensor to Image GmbH

Lechtorstrasse 20 -86956 Schongau - Germany Phone: +49 8861 2369 0 Email: sales.europe@euresys.com

#### AMERICA

#### **Euresys Inc.**

27132-A Paseo Espada - Suite 421 San Juan Capistrano, CA 92675 - United States

Phone: +1 949 743 0612 Email: sales.americas@euresys.com

#### ASIA

#### Euresys Pte. Ltd.

750A Chai Chee Road - #07-15 ESR BizPark @ Chai Chee Singapore 469001 - Singapore

Phone: +65 6445 4800 Email: sales.asia@euresys.com

#### CHINA

#### **Euresys Shanghai Liaison Office**

Unit 802, Tower B, Greenland The Center - No.500 Yunjin Road, Xuhui District 200232 Shanghai - China Euresys上海联络处 上海市徐汇区云锦路500号绿地汇中心B座802室 200232 Phone: +86 21 33686220

Email: sales.china@euresys.com

#### CHINA

#### **Euresys Shenzhen Liaison Office**

Room 1202 - Chinese Overseas Scholars Venture Building 518057 Shenzen - China Euresys深圳联络处 深圳南山区留学生创业大厦1期1202 518057 Phone: +86 755 86506902

Email: sales.china@euresys.com

#### JAPAN

#### Euresys Japan K.K.

Expert Office Shinyokohama - Nisso Dai 18 Building, Shinyokohama 3-7-18, Kohoku Yokohama 222-0033 - Japan 〒222-0033 神奈川県横浜市港北区新横浜3-7-18 日総第18ビル エキスパートオフィス新横浜

Phone: +81 45 594 7259

#### Email: sales.japan@euresys.com

More at www.euresys.com

